



NOTES:

1. USE FLOW SYSTEMS' PREFERRED SUPPLIER BOUNDARY KIT AND SURFACE BOX
2. USE GRANULAR BEDDING MATERIAL UNDER SUPPORT PAVER.
3. INSTALL SURFACE BOX AS PER FLOW SYSTEMS GUIDELINES - REFER DRAWING FSI-SK03-FS.
4. TEST ASSEMBLY AND CONNECTING PRESSURE SEWERS HYDROSTATICALLY AFTER INSTALLATION IN ACCORDANCE WITH PRESSURE SEWER CODE WSA-07. TRAPPED AIR MUST BE REMOVED VIA PRESSURE RELIEVING VALVE ON BOUNDARY KIT.
5. ALL PIPEWORK AND FITTINGS TO BE RATED PN16.
6. ALL PE JOINTS TO BE ELECTROFUSION WELDED - NO COMPRESSION FITTINGS PERMITTED.

BOUNDARY KIT

SIZE A1

REV	DATE	DESCRIPTION	BY	APPROVED
7	17/11/16	ADDED NOTE - TRANSITION COUPLING SPECIFIED	NC	NC
6	07/09/16	UPDATED FORMATTING AND SUPPLIER NOTES	NC	NC
5	01/04/16	AMENDMENTS AS PER FS REQUIREMENTS	NC	NC
4	22/03/16	COSMETIC DRAWING AMENDMENTS	NC	NC
3	15/10/15	PIPEWORK CLARIFICATION, NOTE 2 DELETED	NC	NC
2	12/06/15	ADDED - TEE WITH BLEED VALVE	NC	NC

DESIGNED:	CK
DRAWN:	SR
CHECKED:	RS



DRG TITLE:	PRESSURE SEWER SYSTEM PROPERTY BOUNDARY ASSEMBLY TYPICAL INSTALLATION
------------	---

NOT TO SCALE	REV
DRG No. PSS-1112-FS	7